



Register your product and get support at

www.philips.com/welcome



19PFL3404D/12

22PFL3404D/12

19PFL3404H/12

22PFL3404H/12

19PFL3404D/05

22PFL3404D/05

Quick





Start

Q41G7830813 3A








PHILIPS








1






2




3

1




AAA
x 2





2










4





HDMI	
☆☆☆☆	
YPbPr & AUDIO L/R	
☆☆☆	
SCART	
☆☆	
AUDIO L/R & VIDEO IN	
☆	













Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2009 © Koninklijke Philips Electronics N.V. All rights reserved.

